



## Connect Your World With WiFi Travel Router



1. RJ-45 to WiFi
2. Enhance the WiFi signal
3. Share internet with multiple
4. USB Charger 2.1A
5. Universal plug
6. Universal socket
7. Universal voltage (100-240Vac)
8. Suitable for different application scenarios

### One-piece unit with universal adapter plugs

Power rating: 6A max.100-240Vac (110Vac max.660Watt, 230Vac max.1380Watt)

- A type USB Charge: +5 VDC 2.1A
- Built-in 6A Fuse
- Single plug safety feature
- Power on indicator
- World patents protected
- Built-in children safety shutter

### Wi-Fi Standard

HARDWARE FEATURES	
Interface	1 10/100Mbps WAN/LAN Port 1 Reset Button
Wireless Standards	IEEE 802.11n/g/b
WIRELESS FEATURES	
Wireless Modes	AP Mode, Router Mode, Client Mode, Repeater Mode, Bridge Mode
Wireless Functions	Enable/Disable Wireless Radio, WDS Bridge, WMM, Wireless Statistics
Wireless Security	64/128/152-bit WEP, WPA/WPA2, WPA-PSK/WPA2-PSK



<< Next page >>

### Function of WiFi Router

1. Plug Travel WiFi into the power socket with corresponding plugs.
2. It takes about 30 seconds for Travel WiFi booting the system.

#### a. Cable Connection

- Connect the network cable to RJ45 port on the Travel WiFi
- Search the wireless device on your computer or smart phone and choose the SSID of Travel WiFi by Travel WiFi-XXXX. (XXXX is four digital number assign by manufacturer)
- Input password of "12345678" and then confirm to start to access the network.

#### b. Wireless Connection

- Search the wireless device on your computer or smart phone and choose the SSID of Travel WiFi by Travel WiFi-XXXX. (XXXX is four digital number assign by manufacturer)
- Input password of "12345678" then confirm.
- Type the URL of "http://192.168.16.254/" on IE or other web browser.
- Input the username "admin" and password "admin" under the system prompt.

- System will search the available wireless SSID automatically.
- Choose the SSID you want to connect and click "next"
- Check the information of the SSID which want to connect and input password then click "next".
- Click "next" while the connecting message appears.
- System will takes about 60 seconds to change the setting and reboot. Do not turn off the web browser during the setting time.
- You can access the network while completed message appears.

### Function of charging

1. Plug the 3C device to USB port on the Travel WiFi for charging 3C device.



### Function of multi-national plug adapter

1. Plug Travel WiFi into the power socket with corresponding plugs.
2. Travel WiFi do NOT convert the power voltage.



## Connect Your World With WiFi Travel Router



1. RJ-45 to WiFi
2. Enhance the WiFi signal
3. Share internet with multiple
4. USB Charger 2.1A
5. Universal plug
6. Universal socket
7. Universal voltage (100-240Vac)
8. Suitable for different application scenarios

### One-piece unit with universal adapter plugs

Power rating: 6A max.100-240Vac (110Vac max.660Watt, 230Vac max.1380Watt)

- A type USB Charge: +5 VDC 2.1A
- Built-in 6A Fuse
- Single plug safety feature
- Power on indicator
- World patents protected
- Built-in children safety shutter

### Wi-Fi Standard

HARDWARE FEATURES	
Interface	1 10/100Mbps WAN/LAN Port 1 Reset Button
Wireless Standards	IEEE 802.11n/g/b
WIRELESS FEATURES	
Wireless Modes	AP Mode, Router Mode, Client Mode, Repeater Mode, Bridge Mode
Wireless Functions	Enable/Disable Wireless Radio, WDS Bridge, WMM, Wireless Statistics
Wireless Security	64/128/152-bit WEP, WPA/WPA2, WPA-PSK/WPA2-PSK



<< Next page >>

### Function of WiFi Router

1. Plug Travel WiFi into the power socket with corresponding plugs.
2. It takes about 30 seconds for Travel WiFi booting the system.

#### a. Cable Connection

- Connect the network cable to RJ45 port on the Travel WiFi
- Search the wireless device on your computer or smart phone and choose the SSID of Travel WiFi by Travel WiFi-XXXX. (XXXX is four digital number assign by manufacturer)
- Input password of "12345678" and then confirm to start to access the network.

#### b. Wireless Connection

- Search the wireless device on your computer or smart phone and choose the SSID of Travel WiFi by Travel WiFi-XXXX. (XXXX is four digital number assign by manufacturer)
- Input password of "12345678" then confirm.
- Type the URL of "http://192.168.16.254/" on IE or other web browser.
- Input the username "admin" and password "admin" under the system prompt.

- System will search the available wireless SSID automatically.
- Choose the SSID you want to connect and click "next"
- Check the information of the SSID which want to connect and input password then click "next".
- Click "next" while the connecting message appears.
- System will takes about 60 seconds to change the setting and reboot. Do not turn off the web browser during the setting time.
- You can access the network while completed message appears.

### Function of charging

1. Plug the 3C device to USB port on the Travel WiFi for charging 3C device.



### Function of multi-national plug adapter

1. Plug Travel WiFi into the power socket with corresponding plugs.
2. Travel WiFi do NOT convert the power voltage.



## Connect Your World With WiFi Travel Router



1. RJ-45 to WiFi
2. Enhance the WiFi signal
3. Share internet with multiple
4. USB Charger 2.1A
5. Universal plug
6. Universal socket
7. Universal voltage (100-240Vac)
8. Suitable for different application scenarios

### One-piece unit with universal adapter plugs

Power rating: 6A max.100-240Vac (110Vac max.660Watt, 230Vac max.1380Watt)

- A type USB Charge: +5 VDC 2.1A
- Built-in 6A Fuse
- Single plug safety feature
- Power on indicator
- World patents protected
- Built-in children safety shutter

### Wi-Fi Standard

HARDWARE FEATURES	
Interface	1 10/100Mbps WAN/LAN Port 1 Reset Button
Wireless Standards	IEEE 802.11n/g/b
WIRELESS FEATURES	
Wireless Modes	AP Mode, Router Mode, Client Mode, Repeater Mode, Bridge Mode
Wireless Functions	Enable/Disable Wireless Radio, WDS Bridge, WMM, Wireless Statistics
Wireless Security	64/128/152-bit WEP, WPA/WPA2, WPA-PSK/WPA2-PSK



<< Next page >>

### Function of WiFi Router

1. Plug Travel WiFi into the power socket with corresponding plugs.
2. It takes about 30 seconds for Travel WiFi booting the system.

#### a. Cable Connection

- Connect the network cable to RJ45 port on the Travel WiFi
- Search the wireless device on your computer or smart phone and choose the SSID of Travel WiFi by Travel WiFi-XXXX. (XXXX is four digital number assign by manufacturer)
- Input password of "12345678" and then confirm to start to access the network.

#### b. Wireless Connection

- Search the wireless device on your computer or smart phone and choose the SSID of Travel WiFi by Travel WiFi-XXXX. (XXXX is four digital number assign by manufacturer)
- Input password of "12345678" then confirm.
- Type the URL of "http://192.168.16.254/" on IE or other web browser.
- Input the username "admin" and password "admin" under the system prompt.

- System will search the available wireless SSID automatically.
- Choose the SSID you want to connect and click "next"
- Check the information of the SSID which want to connect and input password then click "next".
- Click "next" while the connecting message appears.
- System will takes about 60 seconds to change the setting and reboot. Do not turn off the web browser during the setting time.
- You can access the network while completed message appears.

### Function of charging

1. Plug the 3C device to USB port on the Travel WiFi for charging 3C device.



### Function of multi-national plug adapter

1. Plug Travel WiFi into the power socket with corresponding plugs.
2. Travel WiFi do NOT convert the power voltage.