



Manual iX-L24 5200mAh /iX-L30 8800mAh

How to charge powerbank

1. Use USB cable with Mini USB connector to connect an adapter or computer to charge the powerbank.
2. The Mini USB plug is for DC input, and the USB plug is for DC output.
(Note: The powerbank only supplies for an identified USB 2.0 port of computer complying with the requirements of limited power source.)
3. The LED will turn on and changing color when the charging powerbank.

How to know remain power

Press the button to check the remain power, led light with different color to indicate the remain power.

Red: 0%-30%

Purple: 30-60%

Blue: 60%-100%

How to use the powerbank

1. Connect USB cable to the powerbank.
2. Choose correct connector to connect the mobile phone or other devices.
3. When the connection is OK, Keep pressing the button for 3 seconds, the LED light on the power bank will turn on, means it's charging your device.
4. Any device of 5V can be recharged anywhere by the powerbank: iPhone, iPod, mobile phone, Bluetooth headset, MP3/MP4, video games consoles...
5. When the device is fully charged, disconnect it with the powerbank, keep pressing the button for 3 seconds and the LED lights will turn off.

Caution:

1. Pls read these instructions carefully as incorrect use of Li-polymer batteries may lead to dangers such as overheating, fuming, catching fire.
2. Please charger the mobile charger completely before the first time using it.
3. Before charging the electric device, please confirm the voltage of the electric device. And adust the voltage from the Powerbank accordingly (only 8800mAh model)